### **Table of Contents**

Lab Bench Solutions	2 - 6
Clean Room Solutions	7 - 8
Wall Mount Solutions and Methods	9 - 14
Floor Mount	15 - 17
Tank Solutions	21 - 22
Freezer Farm INDUSTRIAL	23 - 25
OSHPD The Industry Leader	26
in Earthquake Fastening. Custom Fastening Solutions	27
Vivarium	28
UCSD Shake Table Test	29 - 32






Innovative · Creative

### Lab Bench Solutions

- 1 24" Bar with 3M VHB #4941
- 2 Bio-coated 2" Strap 600lb Rated
- 3 4"x4" Stainless Steel 316 Clean Room 500lb Rated
- 4 2"x3" Stainless Steel 316 Clean Room 300lb Rated
- 5 Bio-coated Contour Grip for **Curved Equipment**
- 6 Microscope Lasso for Extra Large Units
- 7 2"x3" Thumb Lock Buckle 300lb Rated
- 8 2"x2" Thumb Lock Buckle 200lb Rated
- 9 1"x2" Thumb Lock Buckle 100lb Rated



Multiple Environmental Solutions for Fastening and Securing



See Page 1 Flex Mount Line Art #2 #3 #4 #5 The Industry Leader #7 #8 #9

### Lab Bench Solutions

#### DOUBLE STACKED HPLC UNIT

Secured by FlexMount Bar, ThumbLock T6 Buckles To Unit Ganged with T4 and Table Secured with-Cart-To-Wall Strap



Secured by FlexMount Bar, 316 Stainless Steel Plates and Cable Assembly








## Lab Bench Solutions

### TOP-HEAVY ROBOTS

Secured with Thumb Lock™ Fasteners (4-point attachment)



Color Match Buckles to Countertop.



## Lab Bench Solutions

PROTECTING VALUABLE ASSETS


**HPLC** 

Using Patented
Thumb Lock™
Buckle System
To Secure
HPLC

Color match for HPLC application.








Functional · Accessible

# Clean Room Solutions

316 Stainless Steel with 3M<sup>™</sup> VHB (very high bond) Closed-Cell Adhesive in Clean Room Environment

Custom
Solution To
Secure Loose
Countertop
Shelving On
Mobile Racking
System





## Clean Room Solutions

Large Floor
Equipment
Secured with
316 Stainless
Bracket. All
Penetrations are
sealed with
100% Silicone

4"x6" is the Largest Fastener in the Industry 3M™ VHB Acrylic Adhesive Resists Clean Room Solvents.





Innovative · Creative

### Wall Mount Solutions

#### **USER FRIENDLY**

36" of Industrial Velcro™ Adhesive Adhered at a Height of 30" and 60" with a Department of Transportation Rated Seatbelt Closure 4000 lbs

This Innovative **Strap Features** the Easiest **Push Button** Disconnect Buckle *Ever* Made.



"The Straps are working great! Everyone likes them. They especially like the one touch quick disconnect in tight spaces."

Jim Mead, Critical Systems Facilities Engineering, Fred Hutchinson Cancer Research Center, Seattle, Washington



### Wall Mount Solutions

#### FLAM, ACIDS, CORROSIVE CABINETS

Straps Are
Adhered In Two
Locations
With Industrial
Velcro™ Barb
Hook And Loop
Fasteners

Strap Is
Secured To
Unistrut Channel
With Quick
Disconnect
Carabineer

Safe Securing
Method for
Flammable,
Corrosives, Toxic
Cabinets - Will
Not Be Pierced







### Wall Mount Solutions

**REFRIGERATOR** 

Door Locks Keep Contents Inside

Flips Up To Open

Padlock Optional





Quick Disconnect Buckle For Ease Of Removal

Strap Products Are Custom Sewn In Three Colors





### Wall Mount Solutions

# METRO AND MOBILE CARTS

Strap Connects
To Wall Stud
And Shelving
And Weaves
Through Metro
Rack.

Available in Bio-Coated

Cart-To-Wall Securing. Squeeze Buckle To Disconnect.

D-Ring Cinch Around Pole.







# Wall Mount Methods

Double Strut System Installation

Secured Into Each Metal Stud

Equipment Is Then Secured In Multiple Positions



### Wall Mount Methods

INSTALLATION TECHNIQUE FOR STRUT-STRAP SYSTEM

All Installers

Training on

Wall.

Receive Extensive

Locating Electrical, Plumbing and

Obstructions in the

Negative and Posi-

Installers also receive Training in

tive Pressure


Rooms.



Earth magnet to locate center of stud



Stud finder to verify center of



Drill 1/4" hole ending when



Look in hole to see if a stud has been hit



Drill 1/2" hole through stud



1/2" hole through stud (inside



Push Toggler through hole



Spread Toggler



Break Toggler Stems



Toggler secured behind stud



Ready for mounting



Mount item to wall

### Floor Mount Solutions

OSHPD ENGINEERED METHOD FOR THERMO LINE OF 14 ULT FREEZERS

Custom Sewn Ratchets Tested To 4,000 Pound Break Strength

Engineering For Single Ratchet For Smaller Units And Double Ratchet For Large Freezers

Stainless Steel
Nested Plates With
Cable To Floor
Using Hilti Drop
Anchors







### Floor Mount Solutions

Stainless Braided Cable Wrapped Around Leg To Carabineer. Also Available In Coated Cable Or Stainless Closed Link Chain



4x4 Stainless
316 Plate With
3M™ VHB
Adhesive
Secured With
Cable Assembly





### Floor Mount Solutions

Custom Floor Brackets For Adjustable Feet

Custom Design Engineering and Fabrication

Corner Trap
For Equipment
Legs or
Medium Sized
Box Equipment







Innovative · Creative

# 4 Open Shelf Solutions

OPTION 1 Stetchable Shock Cord Pull Down Access See-Through Net

OPTION 2
Book-Keeper
Bar
Lift and
Release Bar

OPTION 3
Double Quick
Disconnect
Buckles with
Netting.
Allows Full Shelf
Access.

OPTION 4
Single Quick
Disconnect
Buckles with
Nylon Strapping.
Allows Full Shelf
Access.









Innovative · Creative

### **Custom Tank Solutions**

LIQUID NITROGREN TANKS

#### TANK CORRAL


Allows for Mobility and Security

#### DOUBLE STRUT TO WALL

With Closed Link Stainless Steel Chain and Carabineer








Innovative · Creative

### **Custom Tank Solutions**

MOBILE FERMENTER TANKS

Structure Built On-Site to Accommodate Rolling Storage Tanks

Heavy-Duty Engineered Structural Bracing





Innovative · Creative


## Freezer Farm Solutions

Most Flexible
Relocation
Method
THE STRUT
STRAP
SYSTEM

Pictured Here Are Two-Tiers Of Powder Coated Wall Strut Installed Into Metal Wall Studs

System Allows For Ease Of Removal For Servicing and Relocation Up and Down The Wall

System Does Not Require Floor Drilling and is The Most Flexible and Widely Used Method In Laboratories.





Innovative · Creative


## Freezer Farm Solutions

FREEZER ISLAND

Center Island Constructed with Double UniStrut Frame

Sturdy Double Reinforced Frame Construction for Multiple Freezer Styles

Straps Installed Prior to Populating Freezers





Innovative · Creative

## Freezer Farm Solutions

CRYO STORAGE ISLAND

Straps Use Velcro<sup>™</sup> Adhesives and Have Quick Disconnect Buckles

Large Freezers are Secured with 2 Straps on Each Side Due to Weight and Higher Center of Gravity.





Certified Installer Revco Thermo

### **OSHPD Solutions**

Exclusive
Manufacturer
and Certified
Installer for
Revco-Thermo
Seismic
Bracing

OEM Launch Fall 2013



Removable Slide-Out Allows For Easy Service and Calibration

## **Custom Fastening Solutions**

### MARBLE SCALE TABLE


Thumb Lock™
T-6 Fasteners
Adhere Table To
Upright With An
Epoxy Adhesive.

Cable Wraps Around Table Support Pipe and Secured Into Wall Strut

### STACKED INCUBATORS

Ganged with 2" x 3" Stainless
Steel Plates in 4 Locations





## Vivarium Solutions

Solutions
Available for
Clean Room,
BSL, Positive
and Negative
Pressure Rooms

#### Typical Items:

Bio-Safety Cabinets

Centrifuges

**Animal Cages** 

Mobile Racks

Counter Top Equipment



Custom-Fabricated Nets, Bars and Straps Are Constructed To Meet Various Height Requirements and Weight Options. Prevent Objects from Toppling Above or at Eye-Level

(Also, See Page 16)



World's Largest Simulated Test

### **UCSD Shake Table**







QuakeHold! was selected to participate in the World's largest shake table experiment constructed to improve all components of hospital and laboratory safety during and after an earthquake. We were responsible for populating the building with upright freezers, deli coolers, refrigerators, upright hoods, countertop equipment and also furnish a lifestyle living room with household furnishings. QuakeHold! fastened many of the items with our OSHPD systems as well as our other non OSHPD methods for countertop or wall mounting. The seismic shaking was rated at up to a 200 year event with severe shaking in excess of two minutes. All fastened items performed above our expectations and we experienced no failures. Those items that were left unsecured toppled over and were destroyed in the shaking.

Elevators, stairwells, structural columns and large sections of sheet rock were destroyed in the shaking. We learned many valuable lessons that will make the hospitals of the future safer for all.

To view our YouTube footage of the simulations go to <a href="www.quakeholdindustrial.com">www.quakeholdindustrial.com</a> and click on the UCSD shake table.



World's Largest Simulated Test

### **UCSD Shake Table**

### SET UP FOR TESTING

(300+ Cameras, Seismic Sensors, GPS Monitoring, Physical Inspections and Documentatin After Each Event, Mercalli Intensity Scale, Securing Methods, 5 Shake Secenarios Conducted)

Minus 80 Freezers

Deli Cooler

Refrigerator

Centrifuges

Metro Racks

Flam Cabinet

Laboratory Items

**Bookcases** 

File Cabinets

Countertop Lab Equipment

TV's

Wall Mounted Shelving







Tested · Approved

## **UCSD** Results

#### MULTIPLE SHAKE EVENTS

Live Earthquake Simulation Demonstrates That Secured items Survived Intact and Unsecured items Toppled.





Items Secured with QuakeHold! Industrial Products withstand Severe Shaking!

Actual Screenshots of the Footage Seen Here:

<u>www.quakeholdindustrial.com</u>

Click on the UCSD Shake Table.

Tested · Approved

# **UCSD Inspections**

#### MULTIPLE SHAKE EVENTS

5 Story Building Experienced Severe Damage

Uninhabitable Red Tagged

### QUAKEHOLD PREVAILED!

Without Our Mitigation Techniques and Fastening Solutions, Items Toppled and Broke.

**Elevator Door Askew** 



**Inspectors Assess Damage** 



Toppled TV and Other Objects

1<sup>st</sup> Flr Structural Damage



**Patient Bed Overturned** 

